



**HOW TO MEASURE FRAME WRAP / ZTILT**

Place the frame, top side down, over the highlighted gray frame image. Ensure the frame is placed as it is shown in the picture. Record the angle of frame wrap from the extreme right side of where the lens ends, not where the frame ends.

**PLEASE NOTE:**

This chart will not work as a measurement tool unless printed at exactly 1 to 1 scale. Be sure that your print options are set to page scaling: none. DO NOT select "fit to printable area".

1 cm

**DEFAULT PERSONALIZATION PARAMETERS**

Wrap	Panto	Vertex
5°	12°	14 mm

**ENGRAVING INDEX**

M = Material DC = Design Code ADD = Addition Power

Product	Design Code
PilotWorks E Progressive	EPI

Since there is an extra segment for near vision at the top of the lens, the minimum distance from the fitting cross to the top of the lens may vary. In its standard configuration, this distance should be a minimum of 14 mm.

